

Little Greene

— PAINT & PAPER 1773 —

WALLPAPER ADVICE

SURFACES

Internal walls and ceilings

Pack Sizes: Roll. Each roll measures approximately 52cm (20½") wide by 10.05m (11yds) long. Area = 5.2sq m (56.3sq ft)

Colour Range: See pattern book.

Environment: Manufactured to ISO 9001:2000 standards. All products are technically supported by an ethical policy regarding sourcing of base materials and health and safety information on wallcovering products

Technical Information: Print Substrate High grade paper from environmentally managed sources

PREPARATION

Existing wallcoverings and linings must be removed. Surfaces must be clean, dry and smooth. Mould contamination must be treated with a proprietary mould cure wash before decorating. New plaster or other absorbent surfaces should be pre-treated with a fungicidally protected adhesive or 'size'. Gloss painted surfaces need to be roughened with sandpaper. If lining paper is used it should be hung horizontally.

HANGING

Use Little Greene Ready Mixed Wallpaper Paste in accordance with the instructions on the pack

1. Measure 50cm (20") out from a corner on a wall adjacent to a window wall and use a plumb line to draw a vertical line from ceiling to floor.
2. Cut the rolls of wallcovering to the required length allowing for pattern match and trimming.
3. Apply paste evenly ensuring that the edges are covered. (NB: for non - woven papers follow instructions on the label to paste the wall)
4. **Fold, keeping the pasted side against itself, and leave to soak for 5 minutes.**
5. **Slide into position aligning one edge of the wallpaper to the vertical line. The other edge should overlap around the corner by 20mm (¾"). Smooth away air bubbles with a brush starting from the centre and squeezing out to the edge. Take care to ensure that you do not transfer paste from the wall onto the surface of the paper.**
6. Trim top and bottom.
7. Repeat process with other lengths, butting edges together and matching pattern as necessary. Use a vinyl overlap adhesive where slight overlapping is unavoidable.
8. Wipe away any surplus paste immediately ensuring that you do not transfer paste from the wall onto the surface of the paper.
9. Ensure that you hang each length of wallpaper in the correct direction.

CLEAN UP

Equipment should be cleaned with clean water and a mild detergent immediately after use.

PRECAUTIONS

Check all room lots for colour and batch codes. Check each length for faults/shading before hanging. After 2 or 3 lengths, check again. If a fault is found stop decorating and immediately report it to your retailer.

Claims can not be accepted for paper hung in excess of one roll where a fault could not reasonably be recognised before hanging.

Always read the wallpaper label and instructions on the paste before use.

Disclaimer - The information on this data sheet is correct to the best of our knowledge and experience. The Little Greene Paint Company reserves the right to modify data contained herein, without notice. The information supplied does not absolve users from responsibility to carry out their own tests and experiments, not does it imply any legally binding assurance of certain properties or suitability for any specific purpose. Conditions of service and application may be beyond our control, so no liability whatsoever can be accepted on the basis of the information supplied herein.

The Little Greene Paint Company Limited, Wood Street, Openshaw, Manchester M11 2FB. England.

Tel: 0845 880 5855 (UK) Tel: +44 161 23 00 880 (Overseas) Fax: 0845 880 5877 (UK) Fax: +44 161 22 33 208 (Overseas)

mail@thelittlegreene.com www.littlegreene.com